

Brief instructions: NOMO Professional "Ready to use

- 1) Spray NOMO Professional directly over the mold infested area. Since the mold may already have spread invisibly, spray the surrounding area as well (approx. 20-30cm).
- Leave NOMO Professional to act for about 15-20 minutes so that the mold becomes inactive.
- Then clean the infested area with water and a sponge, brush and/or pressure washer.
 In some cases, the mold will leave stains or residue. If a bleach or other product is used for removal, rinse very thoroughly to ensure no residue remains.

Allow the surface to dry completely before proceeding to step 4.

4) Reapply NOMO Professional to create an anti-mold barrier. Spray NOMO Professional as a fine mist. Avoid dripping! Allow NOMO Professional to dry completely.

IMPORTANT:

- ⇒ Do not apply NOMO Professional in the rain or in direct sunlight. apply.
- ⇒ Before attempting to remove the mold, first treat the mold-infested area with NOMO Professional
- ⇒ When you scrub a mold-infested surface, the mold spores are thrown into the air and circulate around the room, settling in, allowing the mold to spread further and grow again.
- ⇒ Treating the mold spores with NOMO Professional beforehand eliminates this risk.

Example of a sprayer you will need.

The sprayer must be completely clean and must not contain any chemical residues.

